

## **Soya+ container wax basic candle making instructions**

### **Equipment needed**

A double boiler for melting the wax or a metal bowl over a saucepan of hot water

Thermometer

Metal ladle

Old newspapers – to cover work area!

Container

Wick with metal sustainer attached

Wick holder

Soya+ wax

Optional - Wax Fragrance

### **Instructions**

Attach flat bottom of metal wick sustainer centrally into your container. Use a very small amount of glue or our glue dots to hold in place.

To Melt Wax - Fill the bottom of your double boiler  $\frac{3}{4}$  full with water. Add your wax to the top saucepan.

Gently heat the wax to the recommended temperature over a medium heat (different waxes have different melt points (MP) – see info on wax packet – MP = melt point CP = congealing point P = pour temperature

Pre heat containers to required temperature 60-70 degs C

When wax has melted turn off heat.

Add fragrance if required

Make sure the fragrance is properly mixed in to the wax

Pour gently into your container – support the top of the wick with the wick holder

Leave to set at room temperature

When set, trim wick to about 3-4mm length and you have your very own Soya+ candle!

Our soya+ wax is designed for Minimal contraction, allowing one-fill production

Excellent burning behaviour with low residue on burnt candles

Able to be used in blends with paraffin waxes

Has excellent fragrance release. Some conventional liquid fragrances may lead to undesirable crystallisation in the candle and testing is advisable

The natural vegetable materials contained in Soya+ are responsible for its typical creamy nature and may cause a slight but pleasant odour

Soya+ has a low melting point of 42 to 46 degs C and should be stored in cool dry conditions out of direct sunlight

Contains no hazardous ingredients

No potential dangers to health and environment if used as intended

Skin contact – wash with water

Eye contact – wash with fresh water – min. 10 minutes - consult doctor if necessary

If swallowed – flush oral cavity with water. Drink plenty of water – consult a doctor

Clean up can be done with ordinary soap and water

Fullmoons Cauldron™ PO Box 2173 Ascot Berkshire SL5 0PQ Tel nr. 01344 627 945 Fax nr. 0709 210 3111

[www.fullmoons-cauldron.co.uk](http://www.fullmoons-cauldron.co.uk)

Every care has been taken to compile this information accurately. In view of the fact that the application of this information is outside our control, we disclaim any liability incurred in connection with its application or use